Help Line

Australia	+ 1-800-33-11-77
Canada	+ 1-800-665-4339
México	+ 1-800-234-1185
United States	+ 1-800-955-0959

Fellowes

Australia	+ 61-3-8336-9700
Benelux	+ 31-(0)-76-523-2090
Canada	+ 1-905-475-6320
Deutschland	+ 49-(0)-5131-49770
France	+ 33-(0)-1-30-06-86-80
Italia	+ 39-071-730041
Japan	+ 81-(0)-3-5496-2401
Korea	+ 82-2-3462-2884
Malaysia	+ 60-(0)-35122-1231
Polska	+ 48-(0)-22-771-47-40
Espana	+ 34-91-748-05-01
Singapore	+ 65-6221-3811
United Kingdom	+ 44-(0)-1302-836836
United States	+ 1-630-893-1600

www.fellowes.com

Fellowes 1789 Norwood Avenue, Itasca, Illinois 60143-1095 • USA• 630-893-1600
http://www.fellowes.com

Australia Benelux | Canada China | Deutschland España | France Italia | Japan Korea | Polska Singapore | United Kingdom United States

© 2006 Fellowes, Inc. Part No. 401946

Fellowes POWERSHRED®

SB-15C

Please read these instructions before use.
Veuillez lire ces instructions avant utilisation.
Lea estas instrucciones antes del uso.



CAPABILITIES

Will shred: Paper, credit cards, CD/DVDs, staples and small paper clips

Will not shred: Continuous forms, adhesive labels, transparencies, newspaper, cardboard, large paper clips, laminates or plastic other than noted above

Paper shred size:
Confetti-Cut.....5/32" x 1-1/2" (3.9 x 38mm)

Maximum:
Sheets per pass (Confetti-Cut).....15*
Passes per day.....50-100
Cards/CDs per pass.....1
Cards/CDs per day.....10
Paper width.....9"/229mm
Continuous operation.....20 minutes

*20lb., 8.5"x11" paper at 120v, 60Hz, 5.0Amps; heavier paper, humidity or other than rated voltage may reduce capacity.

IMPORTANT SAFETY INSTRUCTIONS — Read Before Using!

⚠WARNING

- Keep away from children and pets. Keep hands away from paper entry. Always unplug or set safety lock when not in use.
- Keep foreign objects – gloves, jewelry, clothing, hair, etc. – away from shredder openings. If object enters top opening, switch to Reverse (R) to back out object.
- Never use aerosol, petroleum based or other flammable products on or near shredder. Do not use canned air on shredder.
- Do not use if damaged or defective. Do not open shredder head. Do not place near or over heat or water source.
- 15 sheets per pass to avoid jams.

⚠CAUTION

- Avoid touching exposed blades under Confetti-Cut shredder head.
- Use only designated entry for cards/CDs. Keep finger away from CD hole.

OPERATION

Shredder comes ready to use. Insert waste bag for easy disposal.

Continuous operation:
20-minute maximum

NOTE: Shredder runs briefly after each pass to clear entry. Continuous operation beyond 20-minutes will trigger 40-minute cool down period.

Set to Off (0) and plug in

PAPER



Check paper amount | Press Auto-On (I) | Feed into paper entry and release

CARD/CD



Hold card/CD at edge | Press Auto-On (I) | Feed into card/CD entry and release

Set to Off (0) and unplug

Safety Lock prevents accidental operation. To set, wait for shredding to stop, then slide switch toward back until yellow light goes on. For greater safety, always unplug shredder after use.

TROUBLESHOOTING

Paper jam: Set to Off (0) and empty bin. Replace bin, close door, and follow any or all of the below procedures.



Press and hold Reverse (R) | Alternate slowly back and forth | Set to Off (0) and unplug | Open door and cut hanging shreds. Close door. Plug in. | Press and hold Reverse (R)

Indicator lights:

- Make sure door is tightly closed
- Wait 40 minutes for motor to cool down
- Remove and empty bin
- Slide safety lock switch to front to resume shredding

MAINTENANCE

Run regularly in reverse for one minute

Lubricate when bin is full, or immediately, if:
- Capacity decreases
- Motor sounds different, or Shredder stops running

Follow oiling procedure below and repeat twice.



Set to Off (0) | *Apply oil across entry | Press Auto-On (I) | Shred one sheet | Press and hold Reverse (R) 2-3 seconds

⚠CAUTION ***Only use a non-aerosol vegetable oil in long nozzle container such as Fellowes 35250***

WARRANTY

LIMITED WARRANTY Fellowes, Inc. ("Fellowes") warrants the cutting blades of the machine to be free from defects in material and workmanship for 7 years from the date of purchase by the original consumer. Fellowes warrants all other parts of the machine to be free of defects in material and workmanship for 1 year from the date of purchase by the original consumer. If any part is found to be defective during the warranty period, your sole and exclusive remedy will be repair or replacement, at Fellowes' option and expense, of the defective part.
This warranty does not apply in cases of abuse, mishandling, or unauthorized repair. ANY IMPLIED WARRANTY, INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS HEREBY LIMITED IN DURATION TO THE APPROPRIATE WARRANTY PERIOD SET FORTH ABOVE. In no event shall Fellowes be liable for any consequential or incidental damages attributable to this product.
This warranty gives you specific legal rights. The duration, terms, and conditions of this warranty are valid worldwide, except where different limitations, restrictions, or conditions may be required by local law.
For more details or to obtain service under this warranty, please contact us or your dealer.